



## SHIELD AMR for the RMS2

### Exploded Diagram / Kit List



Remove slide plate as per manufactures instructions.

1 - Fit the brass plugs into the large holes in the RMS2.

2 - Place the SHIELD AMR hood on top of the RMSw and make sure the holes are aligned with the holes and brass plugs of the RMS2

3 - Screw in the screws to each of the holes until a tight fit is achieved and there is no movement.

**IMPORTANT!!**  
PLEASE ENSURE ALL FIREARMS ARE CLEAR AND  
SAFE BEFORE CONTINUING



Scan the QR code for video showing how the SHIELD AMR fits to the RMS2



ENSURE THAT YOU KEEP TOOLS SAFE FOR FUTURE USE